


GRAM



- NOTES:
1. S1 Rotary switch for speaker select.
  2. Lever switch for power (OFF position).
  3. Resistance values are indicated in ohm unless otherwise noted. (K=1000, M=1000K).
  4. Capacitance values are indicated in micromicrofarads unless otherwise specified (P=micro-microfards).

Figure 9.